

BASIC MOTION PRINCIPLE

Robot locomotion is the collective name for the various methods that robots use to transport themselves from place to place. **Wheeled robots** are typically quite energy efficient and simple to control. However, other forms of locomotion may be more appropriate for a number of reasons, for example traversing rough terrain, as well as moving and interacting in human environments.

OTHER TYPES OF LOCOMOTION

Stationary

1. Omron Forpheus robot

Wheeled

- Single wheel BB-8
- 2. 4WD OmniDirectional MobileRobot
- 3. Wall Climbing Robot (Metal vs Wall vs Glass)

Legged

Humanoid
 Robot
 (BIOLOID)

Swimming


- 1. Fish robot
- 2. Underwater glider robot

Other

1. Kilobot

STATIONARY ROBOTS

1. OMRON FORPHEUS ROBOT





Robot Motion

- Brand: OMRON Parallel link robot
- Four-axis parallel robot achieves high speed and high precision




Robot Actuator

- Brand: OMRON Servo Motor 1S Series
 - Power range from 50 W to 15 kW
 - 23 bit high resolution encoder
- Battery-free absolute multi-turn encoder
 - Price: RM2919.00

WHEELED ROBOTS & TRACKED ROBOT


1. SINGLE WHEEL BB-8



- Hubless Wheel Drive
- Typically a single wheeled vehicle that sits inside the ball, not physically attached to the ball in any way.
- Turning is accomplished by having a section that hangs down like a pendulum, and can be swung to either side. The mass of the pendulum illustrated here is a heavy flywheel (colored red). A motor can then swing that mass to either side to tilt the ball. Tilting the ball causes the entire robot to move in the direction of the tilt.
- For back and forth stability, the vehicle in the track moves back and forth, countering wobble. For side-to-side stability, the suspended mass is moved from side-to-side to counter that wobble.



♥ Click Image for Gallery




Robot Actuator

- Brand: NEMA 17HS4401 Bipolar Stepper Motor
- Price: RM39.00

- Step Angle: 1.8 deg.
- Holding Torque: 40N.cm (56oz.in)
- Rated Current/phase: 1.7A
- Phase Resistance: 1.5Ohm±10%
- Insulation Resistance: 100MΩ, Min, 500VDC
- Insulation Strength: 500VAC for one minute

2. 4WD OMNI-DIRECTIONAL MOBILE ROBOT





- 90 degree Omni Wheel
- Omni-directional wheels are able to roll freely in two directions. It can either roll like a normal wheel or roll laterally using the wheels along its circumstances.
- It is holonomicomni-directional wheels that a highly maneuverable. It can move in an arbitrary direction continuously without changing the direction of the wheels. It can move back and forth, slideways and rotates at the same position.

Brand: Faulhaber 12V DC Coreless Motor

Price: RM 400

Specs:

| | Power | 17W |
|-------|-------------------|--------|
| Motor | RPM | 120rpm |
| | Diameter | 30mm |
| | Length | 42mm |
| | Total Length | 85mm |
| | Diameter of Shaft | 6mm |
| | Length of Shaft | 35mm |
| | No Load Current | 75m |
| | Load Current | 1400mA |
| | Gearbox Ratio | 64:1 |



Faulhaber 12V DC Coreless Motor with encoder(Aluminum alloy Shell)16002 1 order

US \$96.80

US \$2.50 Coupons For You Get coupons

Quantity:

+ 123 Pieces available

Ships to @ Malaysia

Free Shipping

From China to Malaysia via China Post Registered Air Mail Estimated delivery: 30-30 days

More options ∨

Buy Now


Add to Cart




♡ 16

75-Day Buyer Protection Money back guarantee

3. WALL CLIMBING ROBOT (METAL VS WALL VS GLASS)






METAL SURFACE


- The adsorption mechanism. There are 5
 adsorption modes: permanent magnet,
 electromagnetic, negative pressure, molecular
 force, and mixed adsorption.
- Use a version of magnetic tracks or wheels to create adhesion force upon magnetic surfaces.





BRICK SURFACE

- Suction system.
- Creates 42KG of force into the surface.
- Chassis is carefully design to creates high speed airflow from a turbine and low pressure to generate downforce.



- 1. Horizontal (X-) Cylinder
- 3. Visual Sensor
- 5. Suction Cup
- 7. Slave CPU

- 2. Brush
- 4. Vertical (Y-) Cylinder
- 6. Z-Cylinder
- 8. Rotation Cylinder


GLASS SURFACE

- The robot employs suction pads for adhesion.
- Provide suction force to withstand the payload.
- The robot uses a translational mechanism for the movement.
- With the operating mode of sticking-movingsticking, the robot can complete a series of motions including moving, rotation, and crossing obstacles.
- The rotation of the robot is controlled by adjusting rotation angles of the rotational cylinder.

Brand: CHR-GM37-3429 Carbon Brush
DC 12v Motor

Price: RM 37

- Surface galvanized cover
- ◆Beautiful appearance
- Strong magnetic magnet
- *corrosion resistance
- Increasing carbon brush
- Life above 1000H
- +high-power



LEGGED ROBOTS

1. HUMANOID ROBOT (BIOLOID)



- Gait and support pattern.
- Legged robots require control of leg actuators to maintain balance, sensors to determine foot placement and planning algorithms to determine the direction and speed of movement. The periodic contact of the legs of the robot with the ground is called the gait.
- To maintain locomotion, the center of gravity of the walker must be supported either statically or dynamically. Static support is provided by ensuring the center of gravity is within the support pattern formed by legs in contact with the ground. Dynamic support is provided by keeping the trajectory of the center of gravity located so that it can be repositioned by forces from one or more of its legs.
- Two-legged robots exhibit bipedal motion.



DYNAMIXEL AX-12A DYNAMIXEL \$48.90 SKU: 902-0003-001 UPC: 8809052930196 Condition: New Weight: 0.10 LBS Shipping: Calculated at Checkout Quantity: (1) ADD TO CART SAVE TO WISHLIST

Robot Actuator


- Brand: DYNAMIXEL AX-12A actuator.
- Fully integrated DC Motor + Controller + Driver + Sensor + Reduction Gear + Network in one DC servo module.
- Price: RM 200.00


| Item | Specifications | |
|------------------------|--|--|
| Baud Rate | 7,843 [bps] ~ 1 [Mbps] | |
| Weight | AX-12 (53.5 [g]), AX-12+ (53.5 [g]), AX-12A (54.6 [g]) | |
| Dimensions (W x H x D) | 32 X 50 X 40 [mm] 1.26 X 1.97 X 1.57 [inch] | |
| Resolution | 0.29 [°] | |
| Running Degree | 0 ~ 300 [°] Endless Turn | |
| Motor | Cored | |
| Gear Ratio | 254 : 1 | |
| Stall Torque | 1.5 [N.m] (at 12 [V], 1.5 [A]) | |
| No Load Speed | 59 [rev/min] (at 12V) | |
| Operating Temperature | -5 ~ +70 [°C] | |
| Input Voltage | 9.0 ~ 12.0 [V] (Recommended : 11.1V) | |

SWIMMING ROBOTS

1. FISH ROBOT

- Robot fish can achieve the same type of rapid and maneuverable propulsion as real fish, robot fish need multiple control surfaces.
- The propulsive performance is related to the position, mobility, and hydrodynamic characteristics of the control surfaces.
- A central neural system known as a "Central Pattern Generator" (CPGs) can govern multilink robotic fish locomotion. The CPG is located in every segment, and can connect and stimulate contracting or stretching muscles. The cerebrum, the most anterior part of the brain in vertebrates, can control signal inputs to startup, stop and turn. After the systems form a steady locomotion, the signal from the cerebrum stops and the CPGs can produce and modulate locomotion patterns.





Brand: Waterproof Coreless RC Servo.

Price: RM 150.00

Specs:

CNC metal On the cover In the shell

High-precision Taiwan-made aluminium gears with hard anodizing

High Voltage Coreless Digital Servo

SPECIFICATIONS: Dead band: 1µs

Working frequence: 1520µs / 330hz

Motor: Coreless

Operating Speed 6.0v 0.11 sec/60° Operating Speed 8.4v 0.09 sec/60°


Stall Torque 6.0v 24.7 kg.cm Stall Torque 8.4v 30.3 kg.cm Dimensions: 40.5X20.2X38mm

Weight: 58 g


Wire/Color: JR 265 mm/ -Brown +Red S Orange


Bearing: 2 ball bearings






2. UNDERWATER GLIDER ROBOT





- The robot propelled by buoyancy changes, for which the mechanical force of locomotion, necessary to overcome the drag of the vehicle as it moves through a fluid medium, is supplied by gravitational force in the form of net buoyancy (positive or negative).
- The basic modes are based on their movement in the vertical plane (xz), generating the characteristic "sawtooth pattern" in each cycle of operation.





- Brand: Hitec HS-785HB Servo with 785 Gear Rack Kit
- Price: RM550.00

Specs:


Required pulse: 3-5V peak-to-peak square wave Operating voltage: 4.8-6V Operating temperature range: -20 to +60 °C Operating speed (4.8V): 1.68 s/360° at no load Operating speed (6V): 1.4 s/360° at no load Stall torque at 4.8V: 11 kg/cm Stall torque at 6V: 13.2 kg/cm Operating angle: 630° one side pulse travelling 400 µs Continuous rotation modifiable: yes Direction: clockwise/pulse travelling 1500-1900 µsec Current drain (4.8V): 8 mA idle and 230 mA no load operating Current drain (6V): 8.7 mA idle and 285 mA no load operating Dead bandwidth: 8 µs Motor type: 3 pole ferrite Potentiometer drive: indirect drive Bearing type: 1 bearing and 1 Oilite bushing Gear type: all karbonite gear Connector wire length: 300 mm Dimensions: $59 \times 29 \times 50$ mm Weight: 110 g


OTHER TYPE OF ROBOT 1. KILOBOT





- It uses vibrations of the system for the movement of the system's body.
- Moderately swarm robotic.
- Collective movement is a way of letting to coordinate a group of robots and making them move together as a group in a cohesive way. It's a basic way of making some collective tasks done and can be classified into two types formation and flocking.





• Brand: Seeed Studio 316040001 Mini Vibration Motor

• Price: RM 5.50

| No. 序号 | item 项目 | Measuring Condition 測试条件 | Specification 規格 |
|-----------|-------------------------------|--|----------------------------------|
| 3-1 | Rated Speed 额定转速 | At Rated Voltage and Rated Load 额定电压及负荷下测试 | Min 10,000rpm |
| 3-2 | Rated Current 额定电流 | At Rated Voltage and Rated Load 额定电压及负荷下测试 | 80mA or less 80mA 以下 |
| 3-3 | Starting Voltage 起动电压 | At Rated Load and Step Voltage 额定负载及逐渐升高电压法测试 | DC2.3V or less DC2.3V 以下 |
| 3-4 | Insulation Resistance 绝缘电阻 | DC100V between Lead wire and Case 引线与电机机身之间的绝缘电阻 | 10MΩ Min |
| 3-5 | Insulation Voltage 绝缘电压 | DC50V between Lead wire and Motor Case 引线与电机机身之间施加DC50V电压一分钟 | No Destruction Occurs 不被击穿 |
| 3-6 | Terminal Resistance 端子电阻 | Measure between Terminals 端子间电阻 | 75Ω Max |